



KOAMTAC Fundamentals

Using the KDC Finger Trigger Glove/Charging Cradle Adaptor

KOAMTAC Fundamentals

Using the KDC Finger Trigger Glove Adaptor

The KDC Finger Trigger Glove Adaptor has three primary functions with a KDC200 (1D laser scanner) or KDC300 (2D imager scanner).

- The side-facing connector for the finger trigger cable works for LEFT or RIGHT handed Finger Trigger Gloves.
- The secondary side-facing connector for charging is conveniently located. There is no need to remove the FT cable from the primary side-facing connector.
- The charging cradle pogo-pins on the bottom (for drop-in) compatibility with KOAMTAC charging cradle models CC 2X4 & CC 2X1.



Remove the battery cover screw on the back of the KDC200/KDC250.KDC300. A longer screw will be included in your order.

Remove the rubber USB connector cover on the bottom of your KDC. The cover may be cut at the smallest hinge point. No damage will result from cutting this part from your KDC.



Insert the KDC into the adaptor, ensuring the USB connector is completely engaged in the USB port of the KDC. Once attached the screw hole on the back of the scanner should line up with the adaptor. Fasten the adaptor to the KDC with the supplied screw.

KOAMTAC Fundamentals

Using the KDC Finger Trigger Glove Adaptor

Insert the KDC into the pocket of the Finger Trigger Glove.

- Use the KDC250/300 FTG for the KDC200 Finger Trigger Glove Adaptor.
- Use the KDC350 FTG for the KDC250/300 Finger Trigger Glove Adaptor.



+



Slide the KDC & FTG Adaptor into the Finger Trigger Glove.



Connect the FT cable to one side of the adaptor and use the opposite side for your original USB charging cable.



When using the Finger Trigger Glove adaptor with CC 2X4, simply place them in the charging cradle and begin charging. Be sure the KDC screen is facing the same direction as the KOAMTAC logo on the front of the charger. The LED lights will illuminate when charging contact is made.