

What's in the box?

- 1 KDC Ring Scanner
- 1 Large Finger Stabilizer
- 1 Small Finger Stabilizer



*KDC270 sold separately

Additional KDC270 Accessories:

- Charging Cradle
- Protective Boots
- Finger Trigger Glove

KOAMTAC

116 Village Blvd, Ste 305, Princeton, NJ 08540
+1 609-256-4700 [p](#) | +1 609-228-4373 [f](#)
info@koamtac.com | www.koamtac.com

KOAMTAC

KDC270 Ring Scanner Installation Manual



Installation Instructions

1. Open bottom flap and pull adaptor out of pocket being careful not to strain attached cable. (A,B)

A



B



2. Insert KDC270 into pocket and connect adaptor to bottom of scanner. (C,D)

C



D



3. Slide the KDC270, with adaptor attached, all the way into the pocket and close flap. (E,F)

E



F



4. If finger stabilizer is needed (typically when using scanner with 1 finger): open bottom strap and insert best-fitting stabilizer with broader side closest to scan button. (G, H, I)

G



H



I



Removal Instructions

1. Open flap and remove KDC270 half-way; any further may cause damage to the cable. (J,K)

J



K



2. Disconnect the adaptor from KDC270 one side at a time. Do not pull from both sides. (L,M)

L



M



Return adaptor to pocket and close flap for storage.